


Internal boring bars ams



E-SV95CR/L

	Order code	Dimensions (mm)					Insert	Spare parts		
		D	Dmin	L1	L2	F		F1	Screw	Key
steel shank	E0406SV95CR/L 05AMS	6	9,2	56	26	6	4,5	VCGT0501..	VT1604	BT05
	E0408SV95CR/L 05AMS	8	9,2	57	26	5	3			