



# Holder HAMS



## HAMS

Order code	Dimensions (mm)							Spare parts		
	D	D2	d	L	L1	L2	Ex	Screw	Pad	Key
HAMS1604R/L	4	12	16	120	95	25	2,35	AS0043	KVR16	KP1111



## HAMS

Order code	Dimensions (mm)				Spare parts		
	D	d	L	Ex	Screw	Pad	Key
HAMS1606R/L	6	16	120	2,8	AS0043	KVR16	KP1111
HAMS1608R/L	8	16	120	2,8			